



MOTOROLA

DIGITAL WIRELESS
TELEPHONE

User's Guide >

Welcome

Welcome to the world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola T720 GSM wireless phone.

Left Soft Key

Perform functions identified by left display prompt.

Headset Jack

Insert headset accessory for hands-free use.

Power Key & End Key

Turn phone on and off, end phone calls, exit menu system.

Volume Keys

Adjust earpiece and ringer volume.

4-Way Navigation Key

Scroll through menus and lists, set feature values.

Menu Key

Status Light

See incoming call and service status.

Right Soft Key

Perform functions identified by right display prompt.

Voice Key

Record voice notes, phonebook and shortcut names.


Send Key

Send and answer calls, view recent dialed calls list.

Accessory Connector Port

Insert charger and phone accessories.

Microphone



Personal Communications Sector
600 North U.S. Highway 45
Libertyville, Illinois 60048
1-800-331-6456 (United States)
1-888-390-6456 (TTY/TDD United States)
1-800-461-4575 (Canada)

www.motorola.com (United States)
www.motorola.ca (Canada)

MOTOROLA, the Stylized M Logo and all other trademarks indicated as such herein are trademarks of Motorola, Inc. ® Reg. U.S. Pat. & Tm. Off. TrueSync, Sidekick, Starfish and the Stylized Starfish Logo are registered trademarks of Starfish Software, Inc., a wholly owned independent subsidiary of Motorola, Inc. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. All other product or service names are the property of their respective owners.

© 2002 Motorola, Inc. All rights reserved.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual number: 6809441A06-O
Cover number: 8988485L49-O

Contents

Safety and General Information	6
Getting Started	12
What's in the Box?	12
About This Guide	12
Installing the SIM Card	13
Installing the Battery	14
Charging the Battery	16
Battery Use	16
Changing the Convertible Covers	18
Turning Your Phone On	20
Adjusting Volume	20
Making a Call	21
Answering a Call	21
Changing the Call Alert	22
Viewing Your Phone Number	22
Learning to Use Your Phone	23
Using the Display	23
Using the 4-Way Navigation Key	26
Using Menus	27
Entering Text	32
Using the Status Light	39
Using the External Display	40
Locking and Unlocking Your Phone	40
Changing a Code, PIN, or Password	42
If You Forget a Code, PIN, or Password	42
Setting Up Your Phone	44
Storing Your Name and Phone Number	44
Setting the Time and Date	44

Setting a Ring Style	44
Setting Answer Options	45
Setting a Wallpaper Image	46
Setting a Screen Saver Image	47
Zooming In and Out	48
Setting Display Contrast	48
Setting Display Color	48
Adjusting the Backlight	48
Conserving Battery Power	49
Monitoring Battery Charge	49
Calling Features	50
Changing the Active Line	50
Redialing a Number	50
Using Automatic Redial	51
Using Caller ID	51
Canceling an Incoming Call	52
Turning Off a Call Alert	53
Calling an Emergency Number	53
Dialing International Numbers	54
Viewing Recent Calls	54
Returning an Unanswered Call	56
Using the Notepad	57
Attaching a Number	57
Calling With Speed Dial	58
Calling With 1-Touch Dial	58
Using Voicemail	58
Using Call Waiting	60
Putting a Call On Hold	60
Transferring a Call	61
Phone Features	62
Main Menu	62
Feature Quick Reference	64

Specific Absorption Rate Data	75
Additional Health and Safety Information	77
Warranty	85
Product Registration	90
Export Law Assurances	90
Index.	91
Wireless Phone Safety Tips	101

Safety and General Information

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION.
READ THIS INFORMATION BEFORE USING YOUR PHONE.

The information provided in this document supersedes the general safety information contained in user guides published prior to July 2000. For information regarding radio use in a hazardous atmosphere please refer to the Factory Mutual (FM) Approval Manual Supplement or Instruction Card, which is included with radio models that offer this capability.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Operational Characteristics

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits radio frequency (RF) energy. In North America and South America, the phone operates in the frequency ranges of 824 MHz to 849 MHz and 1850 MHz to 1910 MHz in digital mode. In Europe, the Middle East, and Africa, the phone operates in the frequency ranges of 880 MHz to 915 MHz and 1710 MHz to 1785 MHz in digital mode.

When you communicate with your phone, the system handling your call controls the power levels at which your phone transmits. In North and South America, the output power level typically may vary over a range from 0.0 watts to 0.87 watts in digital mode for the 850 MHz band, and 0.00 watts to 0.87 watts in digital mode for the 1900 MHz band. In Europe, the Middle East, and Africa, the output power level typically may vary over a range from 0.0 watts to 1.74 watts in digital mode for the 900 MHz band, and 0.0 watts to 0.87 watts in digital mode for the 1800 MHz band.

Exposure To Radio Frequency Energy

Your Motorola phone is designed to comply with the following national and international standards and guidelines regarding exposure of human beings to radio frequency electromagnetic energy:

- United States Federal Communications Commission, Code of Regulations; 47 CFR part 2 sub-part J
- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition
- National Council on Radiation Protection and Measurements (NCRP) of the United States, Report 86, 1986
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- Ministry of Health (Canada) Safety Code 6. Limits of Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation-Human Exposure) Standard 1999

To assure optimal phone performance and make sure human exposure to radio frequency electromagnetic energy is within the guidelines set forth in the above standards, always adhere to the following procedures:

Portable Phone Operation and EME Exposure

Antenna Care

Use only the supplied or an approved replacement antenna.

Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Do NOT hold the antenna when the phone is in use. Holding the antenna affects call quality and may cause the phone to operate at a higher power level than needed.

Phone Operation

When placing or receiving a phone call, hold your phone as you would a wireline telephone. **Speak directly into the microphone.**

Body-Worn Operation

To maintain compliance with FCC/Health Canada RF exposure guidelines, if you wear a phone on your body when transmitting, always place the phone in a Motorola-supplied or approved clip, holder, holster, case, or body harness for this product. Use of non-Motorola-approved accessories may exceed FCC/Health Canada RF exposure guidelines. If you do not use one of the Motorola-supplied or approved body-worn accessories, and are not using the phone held in the normal use position, **ensure the phone and its antenna are at least one inch (2.5 centimeters) from your body when transmitting.**

Data Operation

When using any data feature of the phone, with or without an accessory cable, **position the phone and its antenna at least one inch (2.5 centimeters) from your body.**

Approved Accessories

For a list of approved Motorola accessories, visit our website at www.mot.com.

Electromagnetic Interference/Compatibility

Note: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.

Facilities

To avoid electromagnetic interference and/or compatibility conflicts, turn off your phone in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.

Aircraft

When instructed to do so, turn off your phone when on board an aircraft. Any use of a phone must be in accordance with applicable regulations per airline crew instructions.

Medical Devices

Pacemakers

The Advanced Medical Technology Association recommends that a minimum separation of 6 inches (15 centimeters) be maintained between a handheld wireless phone and a pacemaker. These recommendations are consistent with the independent research by, and recommendations of, the United States Food and Drug Administration.

Persons with pacemakers should:

- ALWAYS keep the phone more than six inches (15 centimeters) from your pacemaker when the phone is turned ON.
- NOT carry the phone in the breast pocket.
- use the ear opposite the pacemaker to minimize the potential for interference.
- turn OFF the phone immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Safety and General Use While Driving

Check the laws and regulations on the use of phones in the area where you drive. Always obey them.

When using your phone while driving, please:

- give full attention to driving and to the road.
- use hands-free operation, if available.
- pull off the road and park before making or answering a call if driving conditions so require.

Operational Warnings

For Vehicles With an Air Bag

Do not place a portable phone in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a portable phone is placed in the air bag deployment area and the air bag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.

Potentially Explosive Atmospheres

Turn off your phone prior to entering any area with a potentially explosive atmosphere, unless the phone is a model specifically identified as being “Intrinsically Safe.” Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

Note: The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmospheres are often but not always posted.

Blasting Caps and Areas

To avoid possible interference with blasting operations, turn OFF your phone when you are near electrical blasting caps, in a blasting area, or in areas posted: "Turn off two-way radio." Obey all signs and instructions.

Operational Cautions

Antennas

Do not use any portable phone that has a damaged antenna. If a damaged antenna comes into contact with your skin, a minor burn can result.

Batteries

All batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touches exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects.

Getting Started



What's in the Box?

Your digital wireless phone typically comes equipped with a battery and a charger. You can purchase other accessory items to customize your phone for maximum performance and portability.

To purchase Motorola Original™ accessories, contact the Motorola Customer Call Center at 1-800-331-6456 in the United States or 1-800-461-4575 in Canada.

About This Guide

This user guide introduces you to your Motorola wireless phone.

Note: A reference guide for your phone is also available that describes your phone's features in more detail.

To obtain the reference guide for your phone, or another copy of this user guide, see the Motorola Web site at:

<http://motorola.com/consumer/manuals>

or contact the Motorola Customer Call Center at 1-800-331-6456 in the United States or 1-800-461-4575 in Canada.

Optional Features



This label identifies an optional network, SIM card, or subscription-dependent feature that may not be offered by all service providers in all geographical areas. Contact your service provider for more information.

Optional Accessories



This label identifies a feature that requires an optional Motorola Original™ accessory.


Installing the SIM Card

Your SIM (Subscriber Identity Module) card contains your phone number, service details, and phonebook/message memory.

Caution: Do not bend or scratch your SIM card. Avoid exposing your SIM card to static electricity, water, or dirt.


Do This

- 1 If necessary, slide down the battery door release latch and lift the door off of the phone.




**Do This**


- 2 Slide the SIM card latch up.



- 3 Insert the SIM card into the SIM card tray with the notch in the lower left corner and the gold plate facing down.



- 4 Slide the SIM card latch down to lock the SIM card in place.



Installing the Battery

You must install and charge the battery to use your phone.




Your phone is designed to be used only with Motorola Original batteries and accessories. We

recommend that you store batteries in their protective cases when not in use.


Do This

- 1 Remove the battery from its protective clear plastic case.


- 2 If necessary, slide down the battery door release latch and lift the door off of the phone.



- 3 Insert the battery, printed arrow first, **under the tab** at the top of the battery compartment and push down.



- 4 Insert the teeth at the bottom of the battery door into the slot at the base of the phone, then push the door down and snap it into place.




Charging the Battery



New batteries are shipped partially charged. Before you can use your phone, you need to install and charge the battery, as indicated by the following instructions. Some batteries perform best after several full charge/discharge cycles.

Do This

- 1 Plug the travel charger into your phone with the release tab facing up.



- 2 Plug the other end of the travel charger into the appropriate electrical outlet.
- 3 When your phone indicates that the battery is fully charged (**Charge Complete**), press the release tab and remove the travel charger.

Note: When you charge the battery, the battery level indicator in the upper right corner of the display shows how much of the charging process is complete. At least one segment of the battery level indicator must be visible to ensure full phone functionality while charging.

Battery Use

Battery performance depends on many factors, including your wireless carrier's network configuration; signal

strength; the temperature at which you operate your phone; the features and/or settings you select and use; and your voice, data, and other application usage patterns.

Battery Care

Caution: To prevent injuries or burns, do not allow metal objects to contact or short-circuit the battery terminals.

To maximize your battery's performance:

- Always use Motorola Original™ batteries and battery chargers. The phone warranty does not cover damage caused from using non-Motorola batteries and/or battery chargers.
- New batteries or batteries that have been stored for long periods of time may require a longer charge time.
- Maintain the battery at or near room temperature when charging.
- Do not expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- When you do not intend to use a battery for a while, store it uncharged in a cool, dark, dry place, such as a refrigerator.
- Over extended periods of time, batteries gradually wear down and require longer charging times. This is normal. If you charge your battery regularly and notice a decrease in talk time or an increase in charging time, then it is probably time to purchase a new battery.





The rechargeable batteries that power this product must be disposed of properly and may need to be recycled. Refer to your battery's label for battery type. Contact your local recycling center for proper disposal methods. Never dispose of batteries in a fire because they may explode.



Extending Battery Life

- **Turn off the status light**
See page 39.
- **Turn off the screen saver**
See page 47.
- **Minimize keypad-intense functions**
Activities that require intensive keystroke use (such as playing a game or using messaging) reduce your phone's talk and standby time.
- **Turn off the display backlight**
See page 48.
- **Turn on the battery save feature**
See page 49.

Changing the Convertible Covers




You can change the flip cover and battery cover on your phone to personalize its appearance. Matching front and back cover sets are available in a variety of colors and designs.

Your phone is designed to be used only with Motorola Original accessories. See your Motorola retailer for these convertible covers.

Remove a Flip Cover

Do This

Insert your fingertip or fingernail into the slot at the base of the flip cover, then *firmly* pull up and lift the cover off the phone




Notes:

- Do not use tools to remove a flip cover. Using tools to remove a flip cover will damage the cosmetic appearance of the phone.
- The flip cover is attached tightly to the phone, and considerable force is required to remove it.

Attach a Flip Cover

Do This

Insert the tabs at the bottom of the cover into the slots at the base of the phone, then push the cover down and snap it into place.




Turning Your Phone On



Do This

To

- | | | |
|---|-----------------|--------------------|
| 1 | Open your phone | expose the keypad |
| 2 | Press and hold | turn on your phone |



- | | | |
|---|---|----------------------|
| 3 | If necessary, enter your SIM card PIN code and press OK () | unlock your SIM card |
|---|---|----------------------|


Caution: If you enter an incorrect PIN code three times in a row, your SIM card is disabled and your phone displays **SIM Blocked**.

- | | | |
|---|--|-------------------|
| 4 | If necessary, enter your four-digit unlock code and press OK () | unlock your phone |
|---|--|-------------------|

Adjusting Volume

Press the up and down volume keys to:

- increase and decrease earpiece volume during a call







- increase and decrease the ringer volume setting when the idle display is visible (flip must be open)

Tip: At the lowest volume setting, press the down volume key once to switch to vibrate alert. Press it again to switch to silent alert. Press the up volume key to cycle back to vibrate alert, then ring alert.



- turn off an incoming call alert


Making a Call

Press	To
1 keypad keys	dial the phone number
	Tip: If you make a mistake, press DELETE (⏮) to delete the last digit, or press and hold DELETE (⏮) to clear all digits.
2 	make the call
3 	end the call and “hang up” the phone when you are finished

Answering a Call

When you receive a call, your phone rings and/or vibrates and displays an incoming call message.

Press	To
1  or ANSWER (⏮)	answer the call
2 	end the call and “hang up” the phone when you are finished


Tip: When the phone flip is active, simply open the phone to answer the call. (To activate, press  > **Settings** > **In-Call Setup** > **Answer Options** > **Open to Answer**)





Note: If the phone is locked, you must unlock it to answer the call.

Changing the Call Alert

With the phone flip open, press the down volume key to switch the alert for incoming calls and other events to vibrate, then silent. Press the up volume key to reset your phone to ring alert.



Viewing Your Phone Number

To view your phone number from the idle display, press  .

While you are on a call, press  > **My Tel. Numbers**.


Note: Your phone number must be stored on your SIM card to use this feature. To store your phone number on the SIM card, see page 44. If you do not know your phone number, contact your service provider.

Learning to Use Your Phone

See page 1 for a basic phone diagram.



Using the Display



The *idle display* (shown below) is the standard display you see when you are *not* on a call or using the menu.




Press the 4-way navigation key (⤵) left, right, up, or down to select one of the four menu feature icons in the idle display.




The  (menu) indicator in the bottom center of the display indicates you can press the menu key () to go to the main menu to see more features.

Labels at the bottom corners of the display show the current soft key functions. Press the left soft key () or right soft key () to perform the function indicated by the left or right soft key label.

At the top of the display are a number of status indicators:



❶ Signal Strength Indicator Vertical bars show the strength of the network connection. You cannot make or receive calls when the  (no signal) indicator is displayed.





❷ GPRS Indicator Shows that your phone is using a high-speed GPRS network connection. Other indicators can include:


 = GPRS PDP
context active


 = GPRS packet
data available


③ In Use Indicator Shows that a call is in progress.
Other indicators can include:


 = secure CSD
call

 = unsecure CSD
call

 = secure packet
data transfer

 = unsecure packet
data transfer

 = secure
application
connection

 = unsecure
application
connection



④ Roam Indicator Shows that your phone is seeking or using another network system outside your home network. On text entry screens, shows text entry status information:

 = symbol mode


 = numeric mode


 = caps lock on

 = normal text entry




⑤ Active Line Indicator Shows the current active phone line:


 = line 1

 = line 2



⑥ Text Entry Mode Indicator Appears when you are in a text entry screen, to show the current active text entry mode:


 = tap
method


 = iTAP
mode



7 Battery Level Indicator Vertical bars show the battery charge level. Recharge the battery when you see **Low Battery** and hear the low battery alert.


8 Ring Style Indicator Shows the ring style setting.

 = loud ring

 = soft ring


 = vibrate


 = vibrate and ring


 = silent




9 Message Waiting Indicator Appears when you receive a text or email message. Other indicators can include:



 = voicemail message

 = voicemail and text message


 = active chat session

 = limited character count (text entry screen)

Using the 4-Way Navigation Key


Use the 4-way navigation key () like a joystick to navigate the menu system, change feature settings, and play games. From the idle display, press  to select one of the four menu feature icons in the idle display.

4-way navigation key




Tip: Down and up are your primary movements within menus. Move left and right to change feature settings, navigate the datebook, and edit text.

Using Menus

From the idle display, press  to go to the main menu.

Menu Key

Enter menu system, or open a sub-menu, when  appears in bottom center of display.


Current selection.

Left Soft Key

Perform function shown in lower left corner of display (usually **EXIT** or **BACK**).

End Key

Exit menu system without making changes, return to idle display.





Right Soft Key

Perform function shown in lower right corner of display (usually **SELECT** the highlighted menu item).

















4-Way Navigation Key

Scroll **up** or **down** through menus and lists. Scroll **left** or **right** to cycle through and set value of highlighted menu item. From idle display, press **up**, **down**, **left**, or **right** to select menu feature icon.



Press  to highlight a menu feature icon in the main menu. Select **More** () to see additional menu features. The following icons represent features that may appear in

the main menu, depending on your service provider and service subscription options.


Menu Icon	Feature	Menu Icon	Feature
	Media Center		Games & Apps
	Voice Notes		Shortcuts
	Calculator		Settings
	Chat		Web Access
	More		Services
	Web Sessions		Phonebook
	Messages		Datebook
	Recent Calls		Ring Styles




Tip: You can set your phone to display the main menu as a text-based list rather than graphic icons.

Select a Menu Feature

This guide shows you how to select a menu feature as follows, starting from the idle display:


Find the Feature

 > **More** > **Phonebook**

This example shows that from the idle display, you must press , scroll to and select **More** () from the main menu, then scroll to and select **Phonebook**. Use  to scroll, and the left/right soft keys to select the functions listed in the bottom left and right corners of the display.

Select a Feature Option

Some features require you to select an item from a list:




- Press (⬆/⬇) to scroll up or down to highlight the item you want.
- In a numbered list, press a number key to highlight the item.
- In an alphabetized list, press a key multiple times to cycle through the letters on the key and highlight the closest matching list item.



Enter Feature Information


Some features require you to enter information:




Press **CANCEL** () to exit without making changes. **DONE** () appears when you enter or edit information.

- Enter numbers or text with the keypad.
- When an item has a list of possible values, press to the left or right to scroll through and select a value.
- When an item has a list of possible numeric values, press a number key to set the value.
- If you enter or edit information and do not want to save your changes, press to exit without saving.

The message center lets you compose and send text messages. A *flashing cursor* shows where text will appear:




When you enter text using the standard tap method (see page 32), the flashing cursor changes to a *block cursor*, and the soft key functions change:



Entering Text

Multiple text entry methods make it easy for you to enter names, numbers, and messages on your phone.

Choose a Text Mode


Press  > **Entry Method** from any text entry screen to select a text mode:

iTAP	Let the phone predict each word as you enter it. See page 35.
Tap Method	Enter letters, numbers, and symbols by pressing a key one or more times. See page 32.
Numeric	Enter numbers only.
Symbol	Enter symbols only. See page 38.
Browse	Browse your phonebook or recent call lists to select a name or number.

Note: The text mode you select remains active until you change it by selecting another mode.

Use Tap Method

This is the standard mode for entering text on your phone.

Press  > **Entry Method** from any text entry screen and select the **Tap Method** menu option.

Press	To
1 A number key one or more times	select a letter, number, or symbol shown in the “Character Chart” on page 34


Press	To
2 Number keys	enter the remaining characters
3 OK (⏏)	store the text when you are finished

General Text Entry Rules

Press a number key repeatedly to cycle through its characters. See the “Character Chart” on page 34.

Press a number key as many times as necessary to enter the desired character at flashing cursor location.


Press and hold a number key to cycle between text entry modes.



Press **up** or **down** to change letter in block cursor to uppercase or lowercase.











Press **left** or **right** to move flashing cursor to the left or right in text message.



- If you do not press a key for two seconds, the character in the block cursor is accepted, and the cursor moves to the next position.
- The first character of every sentence is capitalized. (Press  down to force the character to lowercase while it is highlighted by the block cursor.)

Character Chart


Use this chart as a guide for entering characters with the tap method.

1 	space . 1 ? ! , @ _ & ~ : ; " - () ' ÿ ÿ % £ \$ ¥ ¤ €
2 	a b c 2 ä å á à â ã α ó β ç
3 	d e f 3 δ ë é è ê ε é φ
4 	g h i 4 ï í î γ η ή ι í
5 	j k l 5 κ λ
6 	m n o 6 ñ ö ø ó ò ô õ μ ν ω ó
7 	p q r s 7 π β σ
8 	t u v 8 θ ü ú ù û τ
9 	w x y z 9 ξ ψ
0 	+ - 0 x * / \ [] = > < # §



Note: This chart may not reflect the exact character set available on your phone.

Use iTAP™ Software Predictive Text Entry Method

iTAP™ software is a predictive text entry method that lets you enter a word using one keypress per letter.

Press  > **Entry Method** from any text entry screen and select the **iTAP** menu option.

Entering Words


Do This	To
1 Press a number key one time	enter the first letter of the word The letters associated with the key are shown at the bottom of the display.
2 Press number keys (one per letter)	enter the rest of the word Alternative words and letter combinations are shown at the bottom of the display. The word choices are updated with each keypress.
3 Press 	highlight the word you want
4 Press SELECT ()	enter the word at the flashing cursor location A space is automatically inserted after the word.



For example, to spell the word “act,” press **2 ABC** **2 ABC** **8 TUV**.
The display shows:

Flashing
cursor
indicates
insertion
point.

Press
DELETE (⏏)
to clear the
last letter.



Press **⬅➡** to
scroll and see
additional word
choices.

Press
SELECT (⏏)
to insert the
highlighted
word.

Entering Novel Words

You may enter a word that the iTAP software does not recognize. If the word is not displayed:

Do This	To
1 Press DELETE (⏏) one or more times	delete letters until you see a letter combination that matches the start of the word
2 Press ⬅➡	highlight the letter or letter combination
3 Press SELECT (⏏), then press ⬅➡ to the left	shift the text entry cursor to the left and “lock” the selected word portion
4 Continue to enter letters and highlight letter combinations	spell the word



Your phone stores the unrecognized word, and includes it in the list of alternative word choices the next time you enter it. When memory space for storing unrecognized words is filled, your phone deletes the oldest words as new words are added.

Entering Punctuation

Press	To
or	enter punctuation or other characters as shown in the “Character Chart” on page 34

Using Capitalization

The first word of a sentence is automatically capitalized, with following words in lowercase.

Press	To
up or down	change the words to initial character capitalized, all uppercase characters, or all lowercase characters

Entering Numbers

Do This	To
1 Enter the first digit and then highlight it	put the iTAP software in number entry mode
2 Press number keys	add digits to the number



Do This	To
3 Press SELECT (⏏)	enter the number at the flashing cursor location

Deleting Letters and Words

Place the cursor to the right of the text you want to delete, and then do the following:

Do This	To
Press DELETE (⏏)	delete one letter at a time
Hold DELETE (⏏)	delete the entire message

Use Symbol Mode

Your phone provides an alternate way to enter symbol characters in a message. Press **☰** > **Entry Method** from any text entry screen and select the **Symbol** menu option.

Do This	To
1 Press a number key one time	display its symbol options at the bottom of the display See the “Symbol Chart” on page 39.
2 Press ⬅	highlight the symbol you want
or	
Press the number key multiple times	
3 Press SELECT (⏏)	enter the symbol at the flashing cursor location


Symbol Chart

Use this chart as a guide for entering characters in symbol mode.

1 _ @	space . ? ! , @ _ & ~ : ; " - () ' ` i % £ \$ ¥ ¤ €
2 ABC	@ _ \
3 DEF	/ : ;
4 GHI	" & '
5 JKL	() [] { }
6 MNO	` i ~
7 PQRS	< > =
8 TUV	\$ £ ¥ ¤ €
9 WXYZ	# % *
0 +	+ - x * / = > < # §

Using the Status Light

The status light shows when you have an incoming call or message, or when your phone is *roaming* (using a non-home system).



Indication	State
alternating red/green	incoming call
flashing green	in service, home system



Indication	State
flashing yellow	roaming, non-home system
flashing red	no service

You can turn off the status light to increase your phone's *standby time*, the length of time that your phone's battery retains power when the phone is turned on but is not in use.

To turn the status light on or off:

Find the Feature

- > Settings
- > Initial Setup
- > Status Light

Using the External Display

When the flip is closed, the external display shows time, date, and phone status information. It also displays messages to notify you of incoming calls and other events. See pages 24–26 for descriptions of the status indicators that may appear in the external display.

Locking and Unlocking Your Phone

You can lock your phone manually or set the phone to lock automatically whenever you turn it off.

To use a locked phone, you must enter the unlock code. A locked phone still rings or vibrates for incoming calls or messages, *but you must unlock it to answer.*

You can make emergency calls on your phone even when it is locked. For more information, see page 53.

Lock Your Phone Manually

Find the Feature

 > **Settings** > **Security**
> **Phone Lock**
> **Lock Now**

Press	To
1 keypad keys	enter your unlock code
2 OK (⏏)	lock the phone

Unlock Your Phone

Tip: Your phone's unlock code is originally set to 1234 at the factory. Many service providers reset the unlock code to the last four digits of your phone number.

At the **Enter Unlock Code** prompt:

Press	To
1 keypad keys	enter your unlock code
2 OK (⏏)	unlock your phone

Set Your Phone to Lock Automatically

You can set your phone to lock every time you turn it off:

Find the Feature

 > **Settings** > **Security**
> **Phone Lock**
> **Automatic Lock** > **On**





Press	To
1 keypad keys	enter your unlock code
2 OK (⏏)	activate automatic lock

Changing a Code, PIN, or Password

Your phone's four-digit unlock code is originally set to 1234, and the six-digit security code is originally set to 000000 at the factory. Your service provider may reset these numbers before you receive your phone.

If your service provider has *not* reset these numbers, we recommend that you change them to prevent other users from accessing your personal information. The unlock code must contain four digits, and the security code must contain six digits.

You can also reset your SIM card PIN code, PIN2 code, and/or call barring password if necessary.

To change a code or password:



Find the Feature

 > Settings > Security
> New Passwords

If You Forget a Code, PIN, or Password

If you forget your security code, SIM card PIN code, PIN2 code, or call barring password, contact your service provider.

If you forget your unlock code, try entering 1234 or the last four digits of your phone number. If that does not work, do the following at the **Enter Unlock Code** prompt:

Press		To
1		go to the unlock code bypass screen
2	keypad keys	enter your security code
3	OK ()	submit your security code



Setting Up Your Phone

Storing Your Name and Phone Number



To store or edit user name and phone number information on your SIM card:

Find the Feature

- > Settings
- > Phone Status
- > My Tel. Numbers

If you do not know your phone number, contact your service provider. To view your phone number from the idle display or during a call, see page 22.

Setting the Time and Date

You must set the time and date to use the datebook.


Find the Feature


- > Settings
- > Initial Setup
- > Time and Date

Setting a Ring Style

Your phone rings or vibrates to notify you of an incoming call or other event. This ring or vibration is called an *alert*.


You can select one of five different ring styles:

 = loud ring

 = soft ring

 = vibrate

 = vibrate and ring



 = silent


The ring style indicator in the display shows the current ring style (see page 24).

To set a ring style:

Find the Feature

 > More > Ring Styles
> Style


Press	To
1 	scroll to the ring style
2 SELECT ()	select the ring style

Each ring style contains settings for specific event alerts, ringer ID, and ringer and keypad volume. To change these settings, press  > More > Ring Styles > Style **Detail**.

Setting Answer Options

You can use different methods to answer an incoming call.

Find the Feature

 > Settings
> In-Call Setup
> Answer Options

The **Answer Options** menu includes:

Multi-Key

answer by pressing any key

Open to Answer

answer by opening the flip












Setting a Wallpaper Image

You can set a picture or animation as a wallpaper (background) image in your phone's idle display.

Note: When you set an animation as a wallpaper image, only the first frame of the animation is displayed.

Find the Feature

 > **Settings**
> **Personalize**
> **Wallpaper**

Press	To
1 	scroll to Picture
2 CHANGE ()	open the picture viewer
3  up or down	scroll to a picture/animation Scroll to (None) to turn off the wallpaper image.
4 SELECT ()	select the image
5 	scroll to Layout
6 CHANGE ()	adjust the image layout
7 	scroll to Center or Tile Center places the image in the center of the display and, if necessary, shrinks the image to fill the display. Tile fills the display with adjacent copies of the image
8 SELECT ()	confirm the layout setting
9 DONE ()	save wallpaper settings



Setting a Screen Saver Image










You can set a picture or animation as a screen saver image. The image is displayed when no activity is detected for a specified time period.

The screen saver image is shrunk to fill the display, if necessary. An animation repeats for one minute, then the first frame of the animation is displayed.

Note: The screen saver is displayed only when your phone is open.



Find the Feature

 > **Settings**
> **Personalize**
> **Screen Saver**

Press	To
1 	scroll to Picture
2 CHANGE ()	open the picture viewer
3  up or down	scroll to a picture/animation Scroll to (None) to turn off the screen saver image.
4 SELECT ()	select the image
5 	scroll to Delay
6 CHANGE ()	set the delay interval
7 	scroll to the inactivity interval that triggers the screen saver
8 SELECT ()	confirm the delay setting
9 DONE ()	save screen saver settings



Zooming In and Out

Press and release , then press and hold  to zoom in and out on display text. Zoom in to increase text size, zoom out to display more information.

You can also zoom in and out from the menu:

Find the Feature

 > Settings
> Initial Setup > Zoom

Setting Display Contrast

Find the Feature

 > Settings
> Initial Setup
> Contrast

Setting Display Color

You can select the color palette that your phone uses to display indicators, highlights, and soft key labels.

Find the Feature

 > Settings
> Personalize
> Color Style

Adjusting the Backlight

You can set the amount of time that the display and keypad backlights remain on, or turn off backlights to conserve battery power.

Find the Feature

 > Settings
> Initial Setup
> Backlight



Conserving Battery Power

Some networks and phones include a battery save setting to conserve battery power. When this feature is activated, your phone automatically turns off the keypad backlight when it detects that enough ambient light is available.

Find the Feature

-  > Settings
- > Initial Setup
- > Battery Save

Monitoring Battery Charge

To view a detailed battery charge meter:

Find the Feature

-  > Settings
- > Phone Status
- > Battery Meter



Calling Features

For basic instructions on how to make and answer calls, see page 21.

Changing the Active Line



Change the active phone line to make and receive calls from your other phone number.




Note: This feature is available only for dual-line enabled SIM cards.

Find the Feature

- > Settings
- > Phone Status
- > Active Line

The active line indicator in the display shows the current active phone line. See page 24.

Redialing a Number

Press	To
1 	view the dialed calls list
2 	scroll to the entry you want to call
3 	redial the number



Using Automatic Redial



When you receive a busy signal, your phone displays **Call Failed**.

With automatic redial, your phone automatically redials the number. When the call goes through, your phone rings or vibrates one time, displays **Redial Successful**, and then connects the call.

You must turn on automatic redial to use the feature. To turn automatic redial on or off:

Find the Feature

- > **Settings**
- > **Initial Setup**
- > **Auto Redial**

When automatic redial is turned off, you can manually activate the feature to redial a phone number. When you hear a busy signal and see **Call Failed**:

Press

or **RETRY** ()

To

activate automatic redial

Using Caller ID

Incoming Calls



Calling line identification (caller ID) displays the phone number for incoming calls in your phone's external and internal displays.

The phone displays the caller's name when the name is stored in your phonebook, or **Incoming Call** when caller ID information is not available.



Outgoing Calls




You can show or hide your phone number as an ID for the calls that you make.

Find the Feature

- > **Settings**
- > **In-Call Setup**
- > **My Caller ID**

You can override the default caller ID setting when you make a call. While dialing (with digits visible in the display):

Press	To
 > Hide ID/Show ID	hide or show your caller ID for the next call

Canceling an Incoming Call

While the phone is ringing or vibrating:

Press	To
IGNORE (⏏)	cancel the incoming call



Depending on your phone settings and/or service subscription, the call may be forwarded to another number, or the caller may hear a busy signal.



Turning Off a Call Alert


You can turn off your phone's incoming call alert before answering the call.

Press	To
either volume key	turn off the alert

Calling an Emergency Number

Your service provider programs one or more emergency phone numbers, such as 911, that you can call under any circumstances, even when your phone is locked or the SIM card is not inserted.


Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

Press	To
1 keypad keys	dial the emergency number
2 	call the emergency number




Dialing International Numbers

To dial the local international access code:

Do This	To
Press and hold 	insert the international access code (*) for the country from which you are calling




Viewing Recent Calls

Your phone keeps lists of the calls you recently received and dialed, even if the calls did not connect. The lists are sorted from newest to oldest entries. The oldest entries are deleted as new ones are added.







Shortcut: Press  to go directly to the dialed calls list from the idle display.

Find the Feature

 > More > Recent Calls

Press	To
1 	scroll to Received Calls or Dialed Calls
2 SELECT 	select the list
3 	scroll to an entry
Note: ✓ means the call connected.	



Press	To
4 	call the entry's number
<p>Tip: Press and hold  for two seconds to send the number as DTMF tones during a call.</p>	
or	
VIEW 	view entry details
<p>If no details are available, STORE  appears to store the entry in your phonebook. If the entry is already stored, DELETE  appears to delete the entry from the list.</p>	
or	
	open the Last Calls Menu to perform other procedures as described in the following list

The **Last Calls Menu** can include the following options:

Option	Description
Store	Create a phonebook entry with the number in the No. field.
Delete	Delete the entry.
Delete All	Delete all entries in the list.
Hide ID/Show ID	Hide or show your caller ID for the next call.






Option	Description
Send Message	Open a new text message with the number in the To field.
Add Digits	Add digits after the number.
Attach Number	Attach a number from the phonebook or recent call lists.
Send Tones	Send the number to the network as DTMF tones. Note: This option appears only during a call.
Talk then Fax	Talk and then send a fax in the same call. See page 71.



Returning an Unanswered Call

Your phone keeps a record of your unanswered calls, and displays:

- the  (missed call) indicator
- X Missed Calls**, where **X** is the number of missed calls

Press	To
1 VIEW (⏏)	see the received calls list
2 	select a call to return
3 	make the call



Using the Notepad

Your phone stores the most recent string of digits entered on the keypad in a temporary memory location called the *notepad*. This can be a phone number that you called, or a number that you entered but did not call. To retrieve the number stored in the notepad:

Find the Feature

 > More > Recent Calls
> Notepad

Press

To



call the number

or



open the **Dialing Menu** to
attach a number or insert a
special character

or

STORE 

create a phonebook entry
with the number in the **No.**
field

Attaching a Number

While dialing (with digits visible in the display):

Press

To



 > Attach Number

attach a number from the
phonebook or recent call lists



Calling With Speed Dial

Each entry you store in your phonebook is assigned a unique *speed dial* number that identifies the location where the entry is stored in phone memory or on the SIM card. To speed dial a phonebook entry:

Press	To
1 keypad keys	enter the speed dial number for the entry you want to call
2 	submit the number
3 	call the entry

Calling With 1-Touch Dial

To call phonebook entries 1 through 9, just press and hold the one-digit speed dial number for one second.

Tip: You must specify which phone number list you want to use with this feature: phone memory phonebook, or SIM card phonebook. See page 66.

Using Voicemail




You can listen to your voicemail messages by calling your network voicemail phone number. Voicemail messages are stored on the network—not on your phone.

Store Your Voicemail Number


Storing your voicemail number in your phone makes it easy for you to listen to new voicemail messages. In many cases, your service provider has already done this for you.


Find the Feature

 > More > Messages
 > VoiceMail Setup

Press	To
1 keypad keys	enter your voicemail number
2 OK ()	store the number

Receive a Voicemail Message

When you receive a voicemail message, your phone displays the  (voice message waiting) indicator and a **New VoiceMail** notification.

Press	To
CALL ()	listen to the message

Listen to a Voicemail Message

Find the Feature

 > More > Messages
> VoiceMail




The phone calls your voicemail number. If no voicemail number is stored, your phone prompts you to store one.



Using Call Waiting



When you are on a call, an alert tone sounds to indicate that you have received a second call.



Press	To
1	answer the new call
2 SWITCH ()	switch between calls
or	
LINK ()	connect the two calls
or	
	end the call on hold
> End Call On Hold	

You must turn on call waiting to use the feature. To turn call waiting on or off:

Find the Feature

 > **Settings**
> **In-Call Setup**
> **Call Waiting**

Putting a Call On Hold

Press	To
HOLD () (if available) or  > Hold	put the call on hold



Transferring a Call



You can announce that you are transferring an active call to another party, or you can directly transfer the call.

Announce the Call Transfer

Find the Feature

> Hold

Press	To
1 keypad keys	dial the number where you are transferring the call
2	call the number and speak to the person who answers
3	open the menu
4	scroll to Transfer
5 SELECT ()	select Transfer
6 OK ()	confirm the transfer.

Do Not Announce the Call Transfer

Find the Feature

> Transfer


Press	To
1 keypad keys	dial the number where you are transferring the call
2	transfer the call



Phone Features

Main Menu

This is the standard main menu layout. **Menu organization and feature names may vary on your phone.** If you do not find a feature in the main menu, select **More** (☰) to see additional menu features. Not all features may be available for all users.



Settings Menu

Personalize

- Main Menu
- Home Keys
- Color Style
- Greeting
- Banner Graphic
- Wallpaper
- Screen Saver
- Quick Dial

Call Forward

- Voice Calls
- Fax Calls
- Data Calls
- Cancel All
- Forward Status

In-Call Setup

- In-Call Timer
- Call Cost Setup
- My Caller ID
- Talk and Fax
- Answer Options
- Call Waiting

Phone Status

- My Tel. Numbers
- Credit Info/Available
- Active Line
- Battery Meter
- Other Information

Security

- Phone Lock
- Lock Application
- Fixed Dial
- Call Barring
- SIM Pin
- New Passwords

Initial Setup

- Time and Date
- 1-Touch Dial
- Auto Redial
- Backlight
- Status Light
- Zoom
- TTY Setup
- Scroll
- Animation
- Language
- Battery Save
- Contrast
- DTMF
- Master Reset
- Master Clear

Java Tools

- Java System
- Network Access
- DNS IP

Network

Car Settings

Headset







Feature Quick Reference



You can do more with your phone than make and receive phone calls! For example, you can store frequently called numbers in the phonebook for easy dialing, organize your meetings and other events in the datebook, browse the Web, download applications, send messages and email, and more.

This chapter provides information to help you locate features on your phone that are not described in this user guide. For more detailed information, see the reference guide.






Calling Features

Feature	Description
Conference Call	During a call: ☰ > Hold , dial next number, press ☏, press LINK (☐) 
Call Forwarding	Set up or cancel call forwarding: ☰ > Settings > Call Forward 
Call Barring	Restrict outgoing or incoming calls: ☰ > Settings > Security > Call Barring 
TTY Calls	Set up your phone for use with an optional TTY device: ☰ > Settings > Initial Setup > TTY Setup 


Messages

Feature	Description
Send Message	Send a text message:  > More > Messages > Create Message
Receive Message	Read a new text message that you have received: Press READ ()

Chat

Feature	Description
Start Chat	Start a new chat session:  > Chat  > New Chat
Receive Chat Request	When you receive a chat request: Press ACCEPT () or IGNORE ()
End Chat	During a chat session:  > End Chat

Email

Feature	Description
Send Email Message	Send an email message:  > More > Messages > Email Messages  > Create Email



Feature	Description
Receive Email Message	Read a new email message that you have received: Press READ (📖)

Phonebook

Feature	Description
Create Entry	Create a new phonebook entry: 📖 > More > Phonebook 📖 > New > Phone Number or Email Address
Dial Number	Call a number stored in the phonebook: 📖 > More > Phonebook > <i>entry to call</i>
Voice Dial Number	Voice dial a number stored in the phonebook: Press and release the voice key, and say the entry's name (in two seconds)
1-Touch Dial	Set 1-touch dial to call entries stored in your phone memory phonebook or the SIM card phonebook: 📖 > Settings > Initial Setup > 1-Touch Dial






Personalizing Features






Feature	Description
Event Alert	Change an event alert: ☰ > More > Ring Styles > Style Detail > <i>event name</i>
Ring Volume	Adjust ringer volume: ☰ > More > Ring Styles > Style Detail > Ring Volume
Keypad Volume	Adjust keypad keypress volume: ☰ > More > Ring Styles > Style Detail > Key Volume
My Tones	Compose your own ring tones, manage ring tones that you have composed or downloaded: ☰ > Media Center > My Tones
Soft Keys & Menu Icons	Change soft key labels and menu feature icons in the idle display: ☰ > Settings > Personalize > Home Keys
Shortcuts	Create a shortcut to a menu item: Highlight the menu item, then press and hold ☰ Select a shortcut: ☰ > Shortcuts > <i>shortcut name</i>






Menu Features

Feature	Description
Language	Set menu language:  > Settings > Initial Setup > Language
Master Reset	Reset all options <i>except</i> unlock code, security code, lifetime timer:  > Settings > Initial Setup > Master Reset
Master Clear	Reset all options <i>except</i> unlock code, security code, lifetime timer, clear all user settings and entries <i>except</i> SIM card information:  > Settings > Initial Setup > Master Clear

Dialing Features




Feature	Description
Fixed Dial	Turn fixed dialing on or off:  > Settings > Security > Fixed Dial  Use the fixed dial list:  > More > Services > Fixed Dial
Service Dial	Dial service phone numbers:  > More > Services > Service Dial 



Feature	Description
Quick Dial	Dial pre-programmed phone numbers:  > More > Services > Quick Dial
DTMF Tones	Activate DTMF tones:  > Settings > Initial Setup > DTMF Send DTMF tones during a call: Press number keys Send stored numbers as DTMF tones during a call: Highlight a number in the phonebook or recent call lists, then press  > Send Tones








Call Monitoring

Feature	Description
Call Times	View call timers:  > More > Recent Calls > Call Times
In-Call Timer	Display time or cost information during a call:  > Settings > In-Call Setup > In-Call Timer
Call Cost	View call cost trackers:  > More > Recent Calls > Call Cost








Handsfree Features



Feature	Description	
Speaker-phone	Activate a connected external speakerphone during a call: Press SPEAKER (☐) (if available) or ☐ > Spkrphone On	
Auto Answer (car kit or headset)	Automatically answer calls when connected to a car kit or headset: ☐ > Settings > Car Settings or Headset > Auto Answer	
Auto Hands-Free (car kit)	Automatically route calls to a car kit when connected: ☐ > Settings > Car Settings > Auto Handsfree	
Power-Off Delay (car kit)	Set the phone to stay on for a period of time after the ignition is switched off: ☐ > Settings > Car Settings > Power-Off Delay	
Charger Time (car kit)	Charge the phone for a period of time after the ignition is switched off: ☐ > Settings > Car Settings > Charger Time	



Data and Fax Calls

Feature	Description	
Send Data or Fax	Connect your phone to the device, then place the call through the device application	
Receive Data or Fax	Connect your phone to the device, then answer the call through the device application	
Talk Then Fax	Connect your phone to the device, enter the number, press  > Dialing Menu > Talk Then Fax , then press  to make the call	














Network Features

Feature	Description	
Network Settings	View network information and adjust network settings:  > Settings > Network	

Personal Organizer Features

Feature	Description
Add Datebook Event	Add an event to the datebook:  > More > Datebook > day  > New



Feature	Description
View Datebook Event	View or edit event details:  > More > Datebook > <i>day</i> > <i>event name</i>
Event Reminder	View event reminder: VIEW () Dismiss event reminder EXIT ()
Set Alarm	Set the alarm clock (from datebook week view or day view):  > More > Datebook  > Alarm Clock
Turn Off Alarm	Turn off alarm: Press EXIT () or  Set 8-minute delay: Press DELAY ()
Record Voice Note	Record a voice note: Press and hold voice key, speak voice note, release voice key
Play Voice Note	Play back a recorded voice note:  > Voice Notes > <i>voice note</i>
Calculator	Calculate numbers:  > Calculator
Currency Converter	Convert currency:  > Calculator  > Exchange Rate Enter exchange rate, press OK (), enter amount, select \$ function


Security

Feature	Description
SIM PIN	Lock or unlock the SIM card: ☰ > Settings > Security > SIM PIN Caution: If you enter an incorrect PIN code three times in a row, your SIM card is disabled and your phone displays SIM Blocked .
Lock Application	Lock phone applications: ☰ > Settings > Security > Lock Application

News and Entertainment

Feature	Description
Launch Micro-Browser	Start a micro-browser session: ☰ > Web Access > Browser
Web Sessions	Select or create a Web session: ☰ > Web Sessions
Launch Game or Application	Launch a Java game or application: ☰ > Games & Apps , highlight the application, press SELECT (⏏)
Download Game or Application	Download a Java game or application: ☰ > Web Access > Browser , highlight the application, press SELECT (⏏), press DOWNLOAD (⏏)



Feature	Description
Picture Viewer	Manage pictures and animations:  > Media Center > Picture Viewer



Specific Absorption Rate Data

The Motorola T720 GSM wireless phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government and by Health Canada for Canada. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by Health Canada is 1.6W/kg.¹ Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested for use at the ear is 0.82 W/kg, and when worn on the body, as described in this user guide, is 0.62 W/kg. (Body-worn measurements

differ among phone models, depending upon available accessories and regulatory requirements).²

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://phonefacts.net>

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

<http://www.cwta.ca>

1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

**The U.S. Food and Drug
Administration's Center for
Devices and Radiological Health
Consumer Update on Mobile Phones**



FDA has been receiving inquiries about the safety of mobile phones, including cellular phones and PCS phones. The following summarizes what is known—and what remains unknown—about whether these products can pose a hazard to health, and what can be done to minimize any potential risk. This information may be used to respond to questions.

Why the concern?

Mobile phones emit low levels of radio frequency energy (i.e., radio frequency radiation) in the microwave range while being used. They also emit very low levels of radio frequency energy (RF), considered non-significant, when in the stand-by mode. It is well known that high levels of RF can produce biological damage through heating effects (this is how your microwave oven is able to cook food). However, it is not known whether, to what extent, or through what mechanism, lower levels of RF might cause adverse health effects as well. Although some research has been done to address these questions, no clear picture of the biological effects of this type of radiation has emerged to date. Thus, the available science does not allow us to conclude that mobile phones are absolutely safe, or that they are unsafe. However, the available scientific evidence does not demonstrate any adverse health effects associated with the use of mobile phones.

What kinds of phones are in question?

Questions have been raised about hand-held mobile phones, the kind that have a built-in antenna that is positioned close to the user's head during normal telephone conversation. These types of mobile phones are of concern because of the short distance between the phone's antenna—

the primary source of the RF—and the person's head. The exposure to RF from mobile phones in which the antenna is located at greater distances from the user (on the outside of a car, for example) is drastically lower than that from hand-held phones, because a person's RF exposure decreases rapidly with distance from the source. The safety of so-called “cordless phones,” which have a base unit connected to the telephone wiring in a house and which operate at far lower power levels and frequencies, has not been questioned.

How much evidence is there that hand-held mobile phones might be harmful?

Briefly, there is not enough evidence to know for sure, either way; however, research efforts are on-going. The existing scientific evidence is conflicting and many of the studies that have been done to date have suffered from flaws in their research methods. Animal experiments investigating the effects of RF exposures characteristic of mobile phones have yielded conflicting results. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. In one study, mice genetically altered to be predisposed to developing one type of cancer developed more than twice as many such cancers when they were exposed to RF energy compared to controls. There is much uncertainty among scientists about whether results obtained from animal studies apply to the use of mobile phones. First, it is uncertain how to apply the results obtained in rats and mice to humans. Second, many of the studies that showed increased tumor development used animals that had already been treated with cancer-causing chemicals, and other studies exposed the animals to the RF virtually continuously—up to 22 hours per day.

For the past five years in the United States, the mobile phone industry has supported research into the safety of mobile phones. This research has resulted in two findings in particular that merit additional study:

- 1 In a hospital-based, case-control study, researchers looked for an association between mobile phone use and either glioma (a type of brain cancer) or acoustic neuroma (a benign tumor of the nerve

sheath). No statistically significant association was found between mobile phone use and acoustic neuroma. There was also no association between mobile phone use and gliomas when all types of types of gliomas were considered together. It should be noted that the average length of mobile phone exposure in this study was less than three years.

When 20 types of glioma were considered separately, however, an association was found between mobile phone use and one rare type of glioma, neuroepitheliomatous tumors. It is possible with multiple comparisons of the same sample that this association occurred by chance. Moreover, the risk did not increase with how often the mobile phone was used, or the length of the calls. In fact, the risk actually decreased with cumulative hours of mobile phone use. Most cancer causing agents increase risk with increased exposure. An ongoing study of brain cancers by the National Cancer Institute is expected to bear on the accuracy and repeatability of these results.¹

- 2 Researchers conducted a large battery of laboratory tests to assess the effects of exposure to mobile phone RF on genetic material. These included tests for several kinds of abnormalities, including mutations, chromosomal aberrations, DNA strand breaks, and structural changes in the genetic material of blood cells called lymphocytes. None of the tests showed any effect of the RF except for the micronucleus assay, which detects structural effects on the genetic material. The cells in this assay showed changes after exposure to simulated cell phone radiation, but only after 24 hours of exposure. It is possible that exposing the test cells to radiation for this long resulted in heating. Since this assay is known to be sensitive to heating, heat alone could have caused the abnormalities to occur. The data already in the literature on the response of the micronucleus assay to RF are conflicting. Thus, follow-up research is necessary.²

FDA is currently working with government, industry, and academic groups to ensure the proper follow-up to these industry-funded research findings. Collaboration with the Cellular Telecommunications Industry Association (CTIA) in particular is expected to lead to FDA providing research

recommendations and scientific oversight of new CTIA-funded research based on such recommendations.

Two other studies of interest have been reported recently in the literature:

- 1 Two groups of 18 people were exposed to simulated mobile phone signals under laboratory conditions while they performed cognitive function tests. There were no changes in the subjects' ability to recall words, numbers, or pictures, or in their spatial memory, but they were able to make choices more quickly in one visual test when they were exposed to simulated mobile phone signals. This was the only change noted among more than 20 variables compared.³
- 2 In a study of 209 brain tumor cases and 425 matched controls, there was no increased risk of brain tumors associated with mobile phone use. When tumors did exist in certain locations, however, they were more likely to be on the side of the head where the mobile phone was used.

Because this occurred in only a small number of cases, the increased likelihood was too small to be statistically significant.⁴

In summary, we do not have enough information at this point to assure the public that there are, or are not, any low incident health problems associated with use of mobile phones. FDA continues to work with all parties, including other federal agencies and industry, to assure that research is undertaken to provide the necessary answers to the outstanding questions about the safety of mobile phones.

What is known about cases of human cancer that have been reported in users of hand-held mobile phones?

Some people who have used mobile phones have been diagnosed with brain cancer. But it is important to understand that this type of cancer also occurs among people who have not used mobile phones. In fact, brain cancer occurs in the U.S. population at a rate of about 6 new cases per 100,000 people each year. At that rate, assuming 80 million users of

mobile phones (a number increasing at a rate of about 1 million per month), about 4800 cases of brain cancer would be expected each year among those 80 million people, whether or not they used their phones. Thus it is not possible to tell whether any individual's cancer arose because of the phone, or whether it would have happened anyway. A key question is whether the risk of getting a particular form of cancer is greater among people who use mobile phones than among the rest of the population. One way to answer that question is to compare the usage of mobile phones among people with brain cancer with the use of mobile phones among appropriately matched people without brain cancer. This is called a case-control study. The current case-control study of brain cancers by the National Cancer Institute, as well as the follow-up research to be sponsored by industry, will begin to generate this type of information.

What is FDA's role concerning the safety of mobile phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as mobile phones before marketing, as it does with new drugs or medical devices. However, the agency has authority to take action if mobile phones are shown to emit radiation at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of mobile phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions at this time, FDA has urged the mobile phone industry to take a number of steps to assure public safety. The agency has recommended that the industry:

- support needed research into possible biological effects of RF of the type emitted by mobile phones
- design mobile phones in a way that minimizes any RF exposure to the user that is not necessary for device function

- cooperate in providing mobile phone users with the best possible information on what is known about possible effects of mobile phone use on human health

At the same time, FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of mobile phone safety to ensure a coordinated effort at the federal level. These agencies are:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Health and Safety Administration
- National Telecommunications and Information Administration

The National Institutes of Health also participates in this group.

In the absence of conclusive information about any possible risk, what can concerned individuals do?

If there is a risk from these products—and at this point we do not know that there is—it is probably very small. But if people are concerned about avoiding even potential risks, there are simple steps they can take to do so. For example, time is a key factor in how much exposure a person receives. Those persons who spend long periods of time on their hand-held mobile phones could consider holding lengthy conversations on conventional phones and reserving the hand-held models for shorter conversations or for situations when other types of phones are not available.

People who must conduct extended conversations in their cars every day could switch to a type of mobile phone that places more distance between their bodies and the source of the RF, since the exposure level drops off dramatically with distance. For example, they could switch to:

- a mobile phone in which the antenna is located outside the vehicle

- a hand-held phone with a built-in antenna connected to a different antenna mounted on the outside of the car or built into a separate package
- a headset with a remote antenna to a mobile phone carried at the waist

Again, the scientific data do not demonstrate that mobile phones are harmful. But if people are concerned about the radio frequency energy from these products, taking the simple precautions outlined above can reduce any possible risk.

Where can I find additional information?

For additional information, see the following Web sites:

Federal Communications Commission (FCC) RF Safety Program (select "Information on Human Exposure to RF Fields from Cellular and PCS Radio Transmitters"):

<http://www.fcc.gov/oet/rfsafety>

World Health Organization (WHO) International Commission on Non-Ionizing Radiation Protection (select Qs & As): <http://www.who.int/emf>

United Kingdom, National Radiological Protection Board:

<http://www.nrpb.org.uk>

Cellular Telecommunications Industry Association (CTIA):

<http://www.wow-com.com>

U.S. Food and Drug Administration (FDA) Center for Devices and Radiological Health:

<http://www.fda.gov/cdrh/consumer/>

1. Muscat et al. Epidemiological Study of Cellular Telephone Use and Malignant Brain Tumors. In: State of the Science Symposium; 1999 June 20; Long Beach, California.
2. Tice et al. Tests of mobile phone signals for activity in genotoxicity and other laboratory assays. In: Annual Meeting of the Environmental Mutagen Society; March 29, 1999, Washington, D.C.; and personal communication, unpublished results.
3. Preece, AW, Iwi, G, Davies-Smith, A, Wesnes, K, Butler, S, Lim, E, and Varey, A. Effect of a 915-MHz simulated mobile phone signal on cognitive function in man. *Int. J. Radiat. Biol.*, April 8, 1999.
4. Hardell, L, Nasman, A, Pahlson, A, Hallquist, A and Mild, KH. Use of cellular telephones and the risk for brain tumors: a case-control study. *Int. J. Oncol.*, 15: 113-116, 1999.

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

Products Covered	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.

Products Covered	Length of Coverage
Consumer and Professional Two-Way Radio Accessories.	Ninety (90) days from the date of purchase by the first consumer purchaser of the product.
Products and Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

Products Covered	Length of Coverage
Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

Exclusions

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media. Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided “as is” and without warranty.

Who is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent

reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information?

USA	Phones 1-800-331-6456 Two-Way Radios 1-800-353-2729 Pagers 1-800-548-9954
Canada	All Products 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT

(INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

Product Registration

Online Product Registration:

<http://www.motorola.com/warranty>

Product registration is an important step toward enjoying your new Motorola phone. Registering helps us facilitate warranty service, and permits us to contact you should your phone require an update or other service. Registration is for U.S. residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Index

A

- accessories
 - optional 13, 64
 - standard 12
- accessory connector port 1
- active line indicator 24, 25
- alarm clock 72
- alert
 - changing 22
 - creating 67
 - defined 44
 - turning off 21, 53
- animation
 - screen saver 47
 - viewing 74
 - wallpaper 46
- answering a call 21
- automatic redial 51

B

- backlight 48
- barring calls 64
- battery
 - car kit charger time 70
 - charging 16
 - extending battery life
 - 16–18, 40, 48, 49
 - installing 14–15

- battery (continued)
 - level indicator 16, 24, 26
 - meter 49
- block cursor 31
- browse text mode 32

C

- calculator 72
- call
 - adding digits after phone number 56
 - alert 21, 22, 53
 - answer options 45
 - answering 21
 - barring 64
 - barring password,
 - changing 42
 - call waiting 60
 - canceling 52
 - costs 69
 - dialed calls list 54–56
 - dialing 21
 - emergency number 53
 - ending 21
 - forwarding 64
 - hold 60
 - international access code
 - 54

- call (continued)
 - making 21
 - received calls list 54–56
 - recent calls 54–56
 - speakerphone 70
 - talk then fax 56
 - timers 69
 - transferring 61
 - unanswered call 56
- Call Failed** message 51
- call waiting 60
- caller ID 51–52, 55
- calling line identification.
 - See caller ID
- car kit
 - automatic answer 70
 - automatic hands-free 70
 - charger time 70
 - power-off delay 70
- chat 65
- clock
 - illustration 23
- codes
 - changing 42
 - default 41, 42
 - forgetting 42
- color, display 48
- conference call 64
- contrast, display 48
- convertible covers 18–19
- cursor 31

D

- data call
 - receive 71
 - send 71
- date, setting 44
- datebook 72
- datebook icon 23
- diald calls list 54–56
- dialing
 - fixed numbers 68
 - phone number 21
 - quick dial numbers 69
 - service numbers 68
- display
 - backlight 48
 - color 48
 - contrast 48
 - description 23
 - idle display 23, 24
 - illustration 23
 - language 68
 - menu icons, personalizing 67
 - zooming in/out 48
- DTMF tones
 - activating 69
 - sending 55, 56, 69

E

earpiece volume, adjusting 20

email

receiving 66

sending 65

emergency number 53

end key 1, 21, 27

ending a call 21

Enter Unlock Code message 41, 43

external display 40

F

fax call 56

receive 71

send 71

fixed dial 68

flashing cursor 31

flip

activating 22

external display and 40

open to answer 45

using 20

forwarding calls 64

4-way navigation key 1, 26, 27

G

games 73

GPRS indicator 24

H

hands-free use

automatic answer 70

automatic call routing 70

charger time 70

power-off delay 70

speakerphone, activating 70

headset

automatic answer 70

headset jack 1

Hide ID feature 52, 55

hold a call 60

home keys, personalizing 67

I

idle display, defined 23, 24

in use indicator 24, 25

incoming call

canceling 52

Incoming Call message 51

indicators

active line 24, 25

battery level 16, 24, 26

GPRS 24

in use 24, 25

loud ring style 26, 45

menu 23

message waiting 24, 26

missed call 56

indicators (continued)
 ring style 24, 26, 45
 roam 24, 25
 signal strength 24
 silent alert 26
 silent ring style 26, 45
 soft ring style 26, 45
 text entry mode 24, 25
 vibrate and ring style 26,
 45
 vibrate style 26, 45
 voice message waiting
 59
international access code
 54
iTAP software 35–38

J

Java applications 73
joystick 1, 26, 27

K

key
 end 1, 21, 27
 4-way navigation 1, 26,
 27
 left soft key 1, 24, 27, 67
 menu 1, 27, 28
 power 1, 20
 right soft key 1, 24, 27,
 67
 send 1, 21, 54

key (continued)
 voice 1
 volume control 1, 20
keypad
 answering calls 45
 backlight 48
 volume, adjusting 67

L

language, setting 68
left soft key
 functions 1, 24, 27
 personalizing 67
lock
 SIM card 73
lock phone 40
loud ring style indicator 26,
 45

Low Battery message 26

M

making a call 21
master clear 68
master reset 68
menu
 entering text 30, 31, 32,
 38, 39
 icons, changing in idle
 display 67
 icons, described 23
 language, setting 68
 lists 29

- menu (continued)
 - navigating 26, 27
 - using features 29, 31
- menu indicator 23
- menu key 1, 27, 28
- message
 - chat 65
 - picture 65
 - text 65
- message waiting indicator
 - 24, 26
- messages icon 23
- micro-browser
 - browser setup 73
 - Java applications 73
 - using 73
 - Web sessions 73
- microphone 1
- missed call indicator 56
- Missed Calls** message 56
- my telephone number 22,
 - 44
- my tones 67

N

- network settings 71
- notepad 57
- number
 - storing your number 44
 - viewing your number 22
- numeric text mode 32

O

- 1-touch dial
 - setting preference 66
 - using 58
- optional accessory, defined
 - 13
- optional feature, defined 13

P

- passwords. *See* codes
- phone
 - accessories, standard 12
 - active line indicator 25
 - active phone line,
 - changing 50
 - alert 53
 - alert, turning off 21
 - answer options 45
 - clear stored information
 - 68
 - codes 42, 43
 - date, setting 44
 - flip 20, 22
 - keypad, answering calls
 - 45
 - language, setting 68
 - locking 40
 - network settings 71
 - reset all options 68
 - security code 42
 - time, setting 44

- phone (continued)
 - turning on/off 20
 - unlock code 41, 42, 43
 - unlocking 20, 40
- phone number
 - active line indicator 25
 - active phone line,
 - changing 50
 - adding digits after 56
 - attaching two numbers 56, 57
 - international access code 54
 - redialing 50
 - storing in phonebook 66
 - storing your number 44
 - viewing your number 22
- phonebook
 - attaching two numbers 56, 57
 - dialing a number 66
 - icon 23
 - 1-touch dial 58
 - speed dial, using 58
 - storing an entry 66
 - voice dialing 66
- picture
 - screen saver 47
 - viewing 74
 - wallpaper 46

- PIN code
 - changing 42
 - entering 73
- PIN2 code
 - changing 42
- power key 1, 20
- predictive text entry 35–38

Q

- quick dial 69

R

- received calls list 54–56
- recent calls 54–56
- redial
 - automatic redial 51
 - busy number 50
- reference guide 12
- right soft key
 - functions 1, 24, 27
 - personalizing 67
- ring alert
 - changing 22
 - turning off 21, 53
- ring style
 - defined 45
 - indicators 26, 45
 - personalizing 45, 67
 - setting 44–45
- ring style indicator 24, 26, 45
- ring tone, creating 67

ringer volume, adjusting 21,
67
roam indicator 24, 25

S

screen saver 47
security code
 changing 42
 default 42
send key 1, 21, 54
service dial 68
shortcuts
 creating 67
Show ID feature 52, 55
signal strength indicator 24
silent alert indicator 26
silent ring style indicator 26,
45
SIM Blocked message 20,
73
SIM card
 defined 13
 installing 13–14
 locking 73
 PIN code entry 20
 PIN code, changing 42
 PIN2 code, changing 42
 precautions 13
 SIM Blocked message 20,
73

SIM PIN code
 changing 42
 entering 73
SIM PIN2 code
 changing 42
soft keys
 functions 24, 27
 illustration 1
 labels 23
 personalizing 67
soft ring style indicator 26,
45
speakerphone, activating
70
speed dial
 using 58
standby time
 defined 40
status light 1, 39–40
symbol text entry 38–39

T

talk then fax call 56
tap method text entry 32
telephone number
 storing your number 44
 viewing your number 22
text
 block cursor 31
 browse mode 32
 character chart 34

- text (continued)
 - entering from keypad 32, 38, 39
 - entry mode, changing 32
 - flashing cursor 31
 - iTAP software predictive text entry 35–38
 - numeric mode 32
 - symbol chart 39
 - symbol mode 38–39
 - tap method 32
- text entry mode indicator 24, 25
- text mode, changing 32
- time, setting 44
- timers 69
- transfer a call 61
- travel charger, using 16
- TTY device 64

U

- unlock code
 - bypassing 42
 - changing 42
 - default 41, 42
 - entering 20, 41, 42
 - forgetting 42
- unlock phone 40
- user group 73

V

- vibrate alert
 - turning off 21, 53
- vibrate and ring style indicator 26, 45
- vibrate ring style setting 44–45
- vibrate style indicator 26, 45
- voice dial
 - dialing a number 66
- voice key
 - dialing a number 66
 - illustration 1
- voice message waiting indicator 59
- voice notes 72
- voicemail 58–59
- volume
 - earpiece 20
 - keypad 67
 - ringer 21, 67
- volume keys 1, 20

W

- wallpaper 46
- warranty 85–89
- Web access icon 23
- Web pages 73
- Web sessions 73

Z

zooming in/out 48



MOTOROLA

Wireless Phone Safety Tips

"Safety is your most important call!"


Your Motorola wireless telephone gives you the powerful ability to communicate by voice—almost anywhere, anytime, wherever wireless phone service is available and safe conditions allow. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. If you find it necessary to use your wireless phone while behind the wheel of a car, practice good common sense and remember the following tips:

- 1 Get to know your Motorola wireless phone and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.



- 2 **When available, use a hands-free device.** If possible, add an additional layer of convenience to your wireless phone with one of the many Motorola Original™ hands-free accessories available today.
- 3 **Position your wireless phone within easy reach.** Be able to access your wireless phone without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
- 4 **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- 5 **If you receive an incoming call at an inconvenient time do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- 6 **Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic.** Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- 7 **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations which have the potential to divert your attention away from the road.

- 
- 8 **Use your wireless phone to call for help.** Dial 9-1-1 or other local emergency number in the case of fire, traffic accident or medical emergencies.*
- 9 **Use your wireless phone to help others in emergencies.** If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.*
- 10 **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*

* Wherever wireless phone service is available.

Check the laws and regulations on the use of wireless telephones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.



For more information,
please call
1-888-901-SAFE
or visit the
CTIA Web site at
www.wow-com.comTM

ITC00-011



motorola.com

8988485L49-O